

MOTH RGBW Zoom Wash 19x15W

DMX512 Channel Modes

24 Channel Mode

Channel	Function	Value	Description
1	Pan	0-255	0° to 5400°
2	Pan Fine	0-255	16 bit adjustment
3	Tilt	0-255	0° to 270°
4	Tilt Fine	0-255	16 bit adjustment
5	Position Speed	0-255	Speed fast to slow
6	Zoom	0-255	Wide to narrow
7	Master Dimmer	0-255	Linear dimmer from dark to light
8	Strobe	0-3	No function
		4-95	Strobe speed from slow to fast 1-25Hz
		96-176	Random strobe
		177-255	Thunder strobe
9	R1 Dimmer	0-255	Group 1 red from dark to light
10	G1 Dimmer	0-255	Group 1 green from dark to light
11	B1 Dimmer	0-255	Group 1 blue from dark to light
12	W1 Dimmer	0-255	Group 1 white from dark to light
13	R1 Dimmer	0-255	Group 2 red from dark to light
14	G1 Dimmer	0-255	Group 2 green from dark to light
15	B1 Dimmer	0-255	Group 2 blue from dark to light
16	W1 Dimmer	0-255	Group 2 white from dark to light
17	R1 Dimmer	0-255	Group 3 red from dark to light
18	G1 Dimmer	0-255	Group 3 green from dark to light
19	B1 Dimmer	0-255	Group 3 blue from dark to light
20	W1 Dimmer	0-255	Group 3 white from dark to light
21	Effect display (Set CH23 as 50-99)	0-24	Built-in effect 1
		25-49	Built-in effect 2
		50-74	Built-in effect 3
		75-99	Built-in effect 4
		100-124	Built-in effect 5
		125-149	Built-in effect 6
		150-174	Built-in effect 7
		175-199	Built-in effect 8
		200-224	Built-in effect 9
		225-255	Built-in effect 10
22	Effect Speed	0-255	From fast to slow
23	Macro function	0-49	No function
		50-99	Effect display (built-in effect of CH21)
		100-149	Auto run 1
		150-199	Auto run 2
		200-255	Sound control
24	Reset	0-250	No function
		251-255	Reset after 3s

16 Channel Mode

Channel	Function	Value	Description
1	Pan	0-255	0° to 5400°
2	Pan Fine	0-255	16 bit adjustment
3	Tilt	0-255	0° to 270°
4	Tilt Fine	0-255	16 bit adjustment
5	Position Speed	0-255	Speed fast to slow
6	Master Dimmer	0-255	Linear dimmer from dark to light
7	Strobe	0-3	No function
		4-95	Strobe speed from slow to fast 1-25Hz
		96-176	Random strobe
		177-255	Thunder strobe
8	R Dimmer	0-255	Red from dark to light
9	G Dimmer	0-255	Green from dark to light
10	B Dimmer	0-255	Blue from dark to light
11	W Dimmer	0-255	White from dark to light
12	Zoom	0-255	Wide to narrow
13	Effect display (Set CH23 as 50-99)	0-24	Built-in effect 1
		25-49	Built-in effect 2
		50-74	Built-in effect 3
		75-99	Built-in effect 4
		100-124	Built-in effect 5
		125-149	Built-in effect 6
		150-174	Built-in effect 7
		175-199	Built-in effect 8
		200-224	Built-in effect 9
		225-255	Built-in effect 10
14	Effect Speed	0-255	From fast to slow
15	Macro function	0-49	No function
		50-99	Effect display (built-in effect of CH21)
		100-149	Auto run 1
		150-199	Auto run 2
		200-255	Sound control
16	Reset	0-250	No function
		251-255	Reset after 3s